

## SERVICE PACKAGES: NON-TURBO & ECLIPSE CROSS /

PACKAGES	MONTHS OR KMS (WHICHEVER COMES FIRST)
PACKAGE A  Replace engine oil & filter  Inspection 1 to 7	<ul> <li>→ 5 Months or 8,000 km</li> <li>→ 25 Months or 40,000 km</li> <li>→ 35 Months or 56,000 km</li> <li>→ 55 Months or 88,000 km</li> <li>→ 65 Months or 104,000 km</li> <li>→ 95 Months or 152,000 km</li> <li>→ 115 Months or 184,000 km</li> </ul>
<ul> <li>PACKAGE B</li> <li>Replace engine oil &amp; filter</li> <li>Inspect cabin/engine air filters</li> <li>Inspection 1 to 7</li> </ul>	<ul> <li>→ 10 Months or 16,000 km</li> <li>→ 20 Months or 32,000 km</li> <li>→ 40 Months or 64,000 km</li> <li>→ 50 Months or 80,000 km</li> <li>→ 100 Months or 176,000 km</li> <li>→ 110 Months or 176,000 km</li> </ul>
<ul> <li>PACKAGE C</li> <li>Replace engine oil &amp; filter</li> <li>Brake service</li> <li>Inspection 1 to 13</li> </ul>	<ul> <li>→ 15 Months or 24,000 km</li> <li>→ 45 Months or 72,000 km</li> <li>→ 75 Months or 120,000 km</li> <li>→ 165 Months or 264,000 km</li> </ul>
<ul> <li>PACKAGE D</li> <li>Replace engine oil &amp; filter</li> <li>Inspect cabin/engine air filters</li> <li>Brake service</li> <li>Inspection 1 to 13</li> </ul>	<ul> <li>→ 30 Months or 48,000 km</li> <li>→ 60 Months or 96,000 km</li> <li>→ 90 Months or 144,000 km</li> <li>→ 120 Months or 192,000 km</li> <li>→ 150 Months or 240,000 km</li> <li>→ 180 Months or 288,000 km</li> </ul>

### **INSPECTION ITEMS**

- 1. Inspect disc brake pads and rotors
- Check brake hoses for deterioration and leaks
- Inspect driveshaft boots for grease leaks and damage
- 4. Check manual transaxle / transmission oil (if equipped)
- 5. Check transfer case oil (if equipped)
- 6. Check rear axle oil level
- 7. Check drive belt condition

- Inspect ball joints and steering linkage seals for leaks and damage
- 9. Inspect suspension for looseness and damage
- Inspect rear drum brake linings and rear wheel cylinders (except vehicles with disc brakes) for wear and leaks
- Inspect condition on all coolant hoses (radiator and heater)
- 12. Inspect exhaust system
- 13. Audible valve clearance inspection

The following services may be required on a VIN specific level at various maintenance intervals for your vehicle:

- Replace Brake Fluid
- Replace Transmission Fluid
- Replace Rear Differential Fluid
- Replace Transfer Case Fluid
- Replace Coolant
- Replace Standard Spark Plugs
- Replace Platinum Spark Plugs

- Replace Iridium Spark Plugs
- Replace Timing Belt
- Inspect Rear Axle
  Oil Level
- Replace Front Differential Fluid
- Replace drive belts
- Tire Rotation



### SERVICE PACKAGES: TURBO - EVO & RALLIART /

PACKAGES	MONTHS OR KMS (WHICHEVER COMES FIRST)		
PACKAGE A  • Replace engine oil & filter	<ul> <li>→ 3 Months or 5,000 km</li> <li>→ 9 Months or 15,000 km</li> <li>→ 48 Months or 80,000 km</li> <li>→ 18 Months or 30,000 km</li> <li>→ 24 Months or 40,000 km</li> <li>→ 63 Months or 105,000 km</li> <li>→ 33 Months or 55,000 km</li> <li>→ 69 Months or 115,000 km</li> </ul>		
PACKAGE B  Replace engine oil & filter  Inspection 1 to 7	<ul> <li>→ 6 Months or 10,000 km</li> <li>→ 21 Months or 35,000 km</li> <li>→ 36 Months or 60,000 km</li> <li>→ 81 Months or 135,000 km</li> </ul>		
PACKAGE C  Replace engine oil & filter  Inspection 1 to 15	<ul> <li>→ 12 Months or 20,000 km</li> <li>→ 57 Months or 95,000 km</li> <li>→ 27 Months or 45,000 km</li> <li>→ 42 Months or 70,000 km</li> <li>→ 87 Months or 145,000 km</li> </ul>		
<ul> <li>PACKAGE D</li> <li>Replace engine oil &amp; filter</li> <li>Brake service</li> <li>Inspection 1 to 15</li> </ul>	<ul> <li>→ 15 Months or 25,000 km</li> <li>→ 30 Months or 50,000 km</li> <li>→ 45 Months or 75,000 km</li> <li>→ 90 Months or 150,000 km</li> </ul>		

### INSPECTION ITEMS

- 1. Inspect disc brake pads and rotors
- 2. Check brake hoses for deterioration and leaks
- 3. Inspect driveshaft boots for grease leaks and damage
- Check manual transaxle / transmission oil (if equipped)
- 5. Check transfer case oil (if equipped)
- 6. Check rear axle oil level
- 7. Check drive belt condition
- 8. Inspect ball joints and steering linkage seals for leaks and damage

- Inspect suspension for looseness and damage
- Inspect rear drum brake linings and rear wheel cylinders (except vehicles with disc brakes) for wear and leaks
- 11. Inspect condition on all coolant hoses (radiator and heater)
- 12. Inspect exhaust system
- 13. Audible valve clearance inspection
- 14. Check reserve tank fluid level for all wheel control pump
- 15. Check twin clutch sportronic shift transmission for leaks (check oil level)

The following services may be required on a VIN specific level at various maintenance intervals for your vehicle:

- Replace Brake Fluid
- · Replace Transmission Fluid
- · Replace Rear Differential Fluid
- Replace Transfer Case Fluid
- Replace Coolant
- · Replace Iridium Spark Plugs
- Inspect Rear Axle Oil Level
- · Replace drive belts
- · Tire Rotation



### SERVICE PACKAGES: 2022 OUTLANDER /

PACKAGES	MONTHS OR KMS	SERVICES
ESSENTIAL SERVICE  • Rotate Tires	<ul> <li>→ 8,000 KM, 24,000 KM**</li> <li>→ 40,000 KM, 56,000 KM</li> <li>→ 72,000 KM**, 88,000 KM</li> <li>→ 104,000 KM, 120,000 KM**</li> <li>→ 136,000 KM, 152,000 KM</li> <li>→ 168,000 KM**, 184,000 KM</li> <li>→ 200,000 KM, 216,000 KM**</li> <li>→ 232,000 KM, 248,000 KM</li> </ul>	<ul> <li>Top up fluids</li> <li>Visual inspection at 24,000 KM, 72,000 KM, 120,000 KM, 168,000 KM, 216,000 KM</li> <li>Replace air purifier filter &amp; Perform Brake Service</li> </ul>
SERVICE A  Rotate Tires Replace Engine Oil and Filter Inspection 1 to 6	<ul> <li>→ 10 months or 16,000 KM</li> <li>→ 50 months or 80,000 KM</li> <li>→ 70 months or 112,000 KM</li> <li>→ 110 months or 176,000 KM</li> <li>→ 130 months or 208,000 KM</li> </ul>	
SERVICE B  Rotate Tires  Replace Engine Oil and Filter  Inspection 1 to 6	<ul> <li>→ 20 months or 32,000 KM</li> <li>→ 40 months or 64,000 KM</li> <li>→ 80 months or 128,000 KM</li> <li>→ 100 months or 160,000 KM</li> <li>→ 140 months or 224,000 KM</li> <li>→ 160 months or 256,000 KM</li> </ul>	<ul> <li>Check/Replace keyless operation system transmitter battery</li> <li>Check evaporate emission control system for leaks and clogging</li> <li>Check exhaust sytem</li> <li>Check fuel lines</li> <li>Inspect steering gear &amp; linkage, axle and suspension parts</li> </ul>
SERVICE C  Rotate Tires  Replace Engine Oil and Filter  Brake Service  Inspection 1 to 6	<ul> <li>→ 30 months or 48,000 KM</li> <li>→ 90 months or 144,000 KM</li> <li>→ 150 months or 240,000 KM</li> </ul>	<ul> <li>Replace air cleaner filter</li> <li>Change brake fluid</li> <li>Check drive belt</li> <li>Replace air purifier filter</li> </ul>
SERVICE D  Rotate Tires Replace Engine Oil and Filter Brake Service Inspection 1 to 6	<ul> <li>→ 60 months or 96,000 KM</li> <li>→ 120 months or 192,000 KM</li> <li>→ 180 months or 288,000 KM</li> </ul>	<ul> <li>Replace air cleaner filter</li> <li>Change brake fluid</li> <li>Check drive belt</li> <li>Check evaporate emission control system for leaks and clogging</li> <li>Check exhaust sytem</li> <li>Check fuel lines</li> <li>Replace air purifier filter</li> <li>Check/Replace Keyless operation system transmitter battery</li> <li>Inspect steering gear &amp; linkage, axle and suspension parts</li> </ul>

<sup>\*</sup>At 105 months or 168,000 KM: Replace Spark Plugs (Iridium-tipped type) and Change Engine Coolant

### **INSPECTION ITEMS**

- 1. Check brakes lines & cables
- 2. Inspect brake pads and rotors
- 3. Check automatic transaxle/transmission oil or CVT fluid
- 4. Check tire repair sealant expiration date
- 5. Check transfer fluid & differential gear oil
- 6. Inspect propellar shaft & drive shaft boots

### **Service Intervals:**

- A,B,C
- B,A,D
- A,B,C
- B,A,D

A tire rotation is required at every 8,000 KMs. The first appointment can be booked upon vehicle delivery. It will be an opportunity for the dealer to recommend other services.



# SERVICE PACKAGES: 2018-2022 OUTLANDER PHEV /

PHEV PACKAGES	MONTHS OR KMS
SERVICE 1  Rotate Tires Replace Engine Oil and Filter	<ul> <li>→ 5 months or 8,000 KM</li> <li>→ 20 months or 32,000 KM</li> <li>→ 35 months or 56,000 KM</li> <li>→ 125 months or 200,000 KM</li> <li>→ 50 months or 80,000 KM</li> <li>→ 65 months or 104,000 KM</li> <li>→ 155 months or 248,000 KM</li> <li>→ 80 months or 128,000 KM</li> </ul>
<ul> <li>SERVICE 2</li> <li>Rotate Tires</li> <li>Replace Engine Oil and Filter</li> <li>Check Cabin Air Filter</li> <li>Check Engine Air Filter</li> <li>PHEV Multi Point Inspection</li> </ul>	<ul> <li>→ 10 months or 16,000 KM</li> <li>→ 25 months or 40,000 KM</li> <li>→ 40 months or 64,000 KM</li> <li>→ 130 months or 208,000 KM</li> <li>→ 55 months or 88,000 KM</li> <li>→ 70 months or 112,000 KM</li> <li>→ 160 months or 256,000 KM</li> <li>→ 85 months or 136,000 KM</li> <li>→ 175 months or 280,000 KM</li> </ul>
<ul> <li>SERVICE 3</li> <li>Rotate Tires</li> <li>Replace Engine Oil and Filter</li> <li>Brake Service</li> <li>Replace Cabin Air Filter</li> <li>Replace Engine Air Filter</li> <li>PHEV Multi Point Inspection</li> </ul>	<ul> <li>→ 15 months or 24,000 KM</li> <li>→ 30 months or 48,000 KM</li> <li>→ 45 months or 74,000 KM</li> <li>→ 60 months or 96,000 KM</li> <li>→ 75 months or 120,000 KM</li> <li>→ 90 months or 144,000 KM</li> <li>→ 105 months or 192,000 KM</li> <li>→ 135 months or 216,000 KM</li> <li>→ 150 months or 240,000 KM</li> <li>→ 165 months or 264,000 KM</li> <li>→ 180 months or 288,000 KM</li> </ul>

### PHEV MULTI POINT INSPECTION ITEMS

- 1. Check front motor cooling oil leaks
- 2. Check front & rear transaxle oil level & condition
- 3. Inspect disc brake pads & rotors for wear
- 4. Check brake hoses for deterioration or leaks
- 5. Inspect drive shaft boots for grease leaks & damage
- 6. Check tire repair sealant expiration date
- 7. Check fuel hoses condition

- 8. Check drive belts condition
- 9. Check & service exhaust system
- 10. Check rear motor coolant level & condition
- 11. Inspect suspension system for looseness & damage
- 12. Inspect coolant hoses condition
- 13. Inspect high voltage wire for looseness & damage
- 14. Inspect ball joint & steering linkage seals for grease leaks & damage

<sup>\*</sup>At every 35 months or every 56,000 KM: Change brake fluid

<sup>\*</sup>At every 45 months or every 72,000 KM: Check evaporative emission control system for leaks & clogging, Inspect & adjust intake & exhaust valve clearance, Check fuel system for leak

<sup>\*</sup>At 96 months or 192,000 KM: Change engine coolant

<sup>\*</sup>At 105 months or 168,000 KM: Replace spark plugs, iridium tipped type



# SERVICE PACKAGES: 2023 OUTLANDER PHEV /

PHEV PACKAGES	MONTHS OR KMS
SERVICE 1  Rotate Tires  Replace Engine Oil and Filter	<ul> <li>→ 5 months or 8,000 KM</li> <li>→ 65 months or 104,000 KM</li> <li>→ 15 months or 24,000 KM</li> <li>→ 25 months or 40,000 KM</li> <li>→ 85 months or 136,000 KM</li> <li>→ 35 months or 56,000 KM</li> <li>→ 95 months or 152,000 KM</li> <li>→ 45 months or 72,000 KM</li> <li>→ 105 months or 168,000 KM</li> <li>→ 55 months or 88,000 KM</li> <li>→ 115 months or 184,000 KM</li> <li>→ 125 months or 200,000 KM</li> </ul>
<ul> <li>SERVICE 2</li> <li>Rotate Tires</li> <li>Replace Engine Oil and Filter</li> <li>Replace Cabin Air Filter</li> <li>PHEV Multi Point Inspection 1 to 6</li> </ul>	<ul> <li>→ 10 months or 16,000 KM</li> <li>→ 30 months or 48,000 KM</li> <li>→ 50 months or 80,000 KM</li> <li>→ 70 months or 112,000 KM</li> </ul>
<ul> <li>SERVICE 3</li> <li>Rotate Tires</li> <li>Replace Engine Oil and Filter</li> <li>Replace Cabin Air Filter</li> <li>Replace Engine Air Filter</li> <li>PHEV Multi Point Inspection 1 to 14</li> </ul>	<ul> <li>→ 20 months or 32,000 KM</li> <li>→ 40 months or 64,000 KM</li> <li>→ 60 months or 96,000 KM</li> <li>→ 120 months or 192,000 KM</li> </ul>

### PHEV MULTI POINT INSPECTION ITEMS

- 1. Check front & rear motor cooling oil leaks
- 2. Check front & rear transaxle oil level & condition
- 3. Inspect disc brake pads & rotors for wear
- 4. Check brake hoses for deterioration or leaks
- 5. Inspect drive shaft boots for grease leaks & damage
- 6. Check tire repair sealant expiration date
- 7. Check fuel hoses condition

- 8. Check drive belts condition
- 9. Check & service exhaust system
- 10. Check rear motor coolant level & condition
- 11. Inspect coolant hoses condition
- 12. Inspect high voltage wire for looseness & damage
- 13. Inspect ball joint & steering linkage seals for grease leaks & damage
- 14. Inspect suspension system for looseness & damage
- \*At every 15 months or every 24,000 KM: Replace KOS transmitter battery
- \*At every 30 months or every 48,000 KM: Change brake fluid
- \*At every 45 months or every 72,000 KM: Check evaporative emission control system for leaks & clogging, Inspect & adjust intake & exhaust valve clearance, Check fuel system for leak
- \*At 96 months or 192,000 KM: Change engine coolant
- \*At 105 months or 168,000 KM: Replace spark plugs, iridium tipped type